




1290 PE distribution x=200mm y=25mm




Example of a 116PE pulse




Example of a 105PE pulse




Example of a 141PE pulse




Example of a 109PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 185PE pulse




Example of a 207PE pulse




Example of a 139PE pulse




Example of a 141PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 97PE pulse




Example of a 98PE pulse




Example of a 98PE pulse




Example of a 82PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 75PE pulse




Example of a 84PE pulse




Example of a 144PE pulse




Example of a 143PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 100PE pulse




Example of a 78PE pulse




Example of a 98PE pulse




Example of a 92PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 96PE pulse




Example of a 136PE pulse




Example of a 156PE pulse




Example of a 157PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 79PE pulse




Example of a 68PE pulse




Example of a 99PE pulse




Example of a 110PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 66PE pulse




Example of a 85PE pulse




Example of a 298PE pulse




Example of a 323PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 81PE pulse




Example of a 52PE pulse




Example of a 65PE pulse




Example of a 54PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 72PE pulse




Example of a 96PE pulse




Example of a 251PE pulse




Example of a 274PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 285PE pulse




Example of a 280PE pulse




Example of a 50PE pulse




Example of a 52PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 76PE pulse




Example of a 261PE pulse




Example of a 239PE pulse




Example of a 320PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 49PE pulse




Example of a 51PE pulse




Example of a 73PE pulse




Example of a 64PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 101PE pulse




Example of a 301PE pulse




Example of a 95PE pulse




Example of a 113PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 58PE pulse




Example of a 52PE pulse




Example of a 49PE pulse




Example of a 62PE pulse




1290 PE distribution x=200mm y=25mm




Example of a 57PE pulse



Example of a 50PE pulse



Example of a 241PE pulse



Example of a 228PE pulse

