




1034 PE distribution x=2250mm y=25mm




Example of a 47PE pulse




Example of a 44PE pulse




Example of a 59PE pulse




Example of a 52PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 110PE pulse




Example of a 89PE pulse




Example of a 186PE pulse




Example of a 163PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 57PE pulse




Example of a 67PE pulse




Example of a 58PE pulse




Example of a 47PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 58PE pulse




Example of a 68PE pulse




Example of a 245PE pulse




Example of a 174PE pulse




1034 PE distribution x=2250mm y=25mm




1034 PE distribution x=2250mm y=25mm




1034 PE distribution x=2250mm y=25mm




Example of a 65PE pulse




Example of a 64PE pulse




Example of a 85PE pulse




Example of a 77PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 34PE pulse




Example of a 31PE pulse




Example of a 194PE pulse




Example of a 159PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 137PE pulse




Example of a 122PE pulse




Example of a 128PE pulse




Example of a 122PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 99PE pulse




Example of a 269PE pulse




Example of a 255PE pulse




Example of a 326PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 82PE pulse




Example of a 80PE pulse




Example of a 67PE pulse




Example of a 73PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 166PE pulse




Example of a 177PE pulse




Example of a 244PE pulse




Example of a 216PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 74PE pulse




Example of a 75PE pulse




Example of a 86PE pulse




Example of a 70PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 66PE pulse




Example of a 89PE pulse




Example of a 263PE pulse




Example of a 250PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 57PE pulse




Example of a 79PE pulse




Example of a 120PE pulse




Example of a 104PE pulse




1034 PE distribution x=2250mm y=25mm




Example of a 39PE pulse



Example of a 60PE pulse



Example of a 283PE pulse



Example of a 217PE pulse

