




# 1334 PE distribution x=1500mm y=25mm




Example of a 89PE pulse




Example of a 72PE pulse




Example of a 100PE pulse




Example of a 95PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 75PE pulse




Example of a 123PE pulse




Example of a 141PE pulse




Example of a 120PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 45PE pulse




Example of a 50PE pulse




Example of a 50PE pulse




Example of a 66PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 47PE pulse




Example of a 75PE pulse




Example of a 114PE pulse




Example of a 133PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 53PE pulse




Example of a 45PE pulse




Example of a 50PE pulse




Example of a 55PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 45PE pulse




Example of a 55PE pulse




Example of a 222PE pulse




Example of a 228PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 68PE pulse




Example of a 66PE pulse




Example of a 91PE pulse




Example of a 101PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 43PE pulse




Example of a 56PE pulse



Example of a 37PE pulse




Example of a 58PE pulse







# 1334 PE distribution x=1500mm y=25mm




Example of a 81PE pulse




Example of a 77PE pulse




Example of a 87PE pulse




Example of a 94PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 77PE pulse




Example of a 91PE pulse




Example of a 141PE pulse




Example of a 104PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 45PE pulse




Example of a 44PE pulse




Example of a 44PE pulse




Example of a 40PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 61PE pulse




Example of a 59PE pulse




Example of a 112PE pulse




Example of a 115PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 44PE pulse




Example of a 68PE pulse




Example of a 51PE pulse




Example of a 57PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 47PE pulse




Example of a 51PE pulse




Example of a 245PE pulse




Example of a 220PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 33PE pulse




Example of a 23PE pulse




Example of a 54PE pulse




Example of a 67PE pulse




# 1334 PE distribution x=1500mm y=25mm




Example of a 48PE pulse



Example of a 51PE pulse



Example of a 50PE pulse



Example of a 72PE pulse

