




# 1027 PE distribution x=750mm y=25mm




Example of a 125PE pulse




Example of a 120PE pulse




Example of a 212PE pulse




Example of a 209PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 202PE pulse




Example of a 189PE pulse




Example of a 113PE pulse




Example of a 126PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 121PE pulse




Example of a 134PE pulse




Example of a 148PE pulse




Example of a 135PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 102PE pulse




Example of a 94PE pulse




Example of a 96PE pulse




Example of a 91PE pulse




1027 PE distribution x=750mm y=25mm




1027 PE distribution x=750mm y=25mm




# 1027 PE distribution x=750mm y=25mm




Example of a 138PE pulse




Example of a 144PE pulse




Example of a 297PE pulse




Example of a 330PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 123PE pulse




Example of a 84PE pulse



Example of a 121PE pulse




Example of a 122PE pulse







# 1027 PE distribution x=750mm y=25mm




Example of a 110PE pulse




Example of a 108PE pulse




Example of a 153PE pulse




Example of a 162PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 143PE pulse




Example of a 149PE pulse




Example of a 84PE pulse




Example of a 80PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 113PE pulse




Example of a 87PE pulse




Example of a 115PE pulse




Example of a 136PE pulse




1027 PE distribution x=750mm y=25mm




Example of a 74PE pulse




Example of a 84PE pulse




Example of a 55PE pulse




Example of a 75PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 82PE pulse




Example of a 188PE pulse




Example of a 74PE pulse




Example of a 171PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 176PE pulse




Example of a 193PE pulse




Example of a 82PE pulse




Example of a 60PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 49PE pulse




Example of a 56PE pulse




Example of a 122PE pulse




Example of a 111PE pulse




# 1027 PE distribution x=750mm y=25mm




Example of a 62PE pulse



Example of a 74PE pulse



Example of a 56PE pulse



Example of a 63PE pulse

