




799 PE distribution x=200mm y=25mm




Example of a 35PE pulse




Example of a 32PE pulse




Example of a 46PE pulse




Example of a 42PE pulse




799 PE distribution x=200mm y=25mm




Example of a 67PE pulse




Example of a 67PE pulse




Example of a 47PE pulse




Example of a 48PE pulse




799 PE distribution x=200mm y=25mm




Example of a 56PE pulse




Example of a 64PE pulse




Example of a 41PE pulse




Example of a 36PE pulse




799 PE distribution x=200mm y=25mm




Example of a 35PE pulse




Example of a 57PE pulse




Example of a 48PE pulse




Example of a 63PE pulse




799 PE distribution x=200mm y=25mm




Example of a 67PE pulse




Example of a 66PE pulse




Example of a 51PE pulse




Example of a 62PE pulse




799 PE distribution x=200mm y=25mm




Example of a 87PE pulse




Example of a 99PE pulse




Example of a 70PE pulse




Example of a 65PE pulse




799 PE distribution x=200mm y=25mm




Example of a 108PE pulse




Example of a 124PE pulse




Example of a 51PE pulse




Example of a 91PE pulse




799 PE distribution x=200mm y=25mm




Example of a 78PE pulse



Example of a 88PE pulse



Example of a 79PE pulse



Example of a 79PE pulse

