




# 1165 PE distribution x=0mm y=0mm




Example of a 64PE pulse




Example of a 80PE pulse




Example of a 94PE pulse




Example of a 94PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 57PE pulse




Example of a 70PE pulse




Example of a 60PE pulse




Example of a 75PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 69PE pulse




Example of a 77PE pulse




Example of a 118PE pulse




Example of a 100PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 77PE pulse




Example of a 85PE pulse




Example of a 154PE pulse




Example of a 177PE pulse




# 1165 PE distribution x=0mm y=0mm




# 1165 PE distribution x=0mm y=0mm




# 1165 PE distribution x=0mm y=0mm




Example of a 91PE pulse




Example of a 73PE pulse




Example of a 98PE pulse




Example of a 73PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 113PE pulse




Example of a 134PE pulse



Example of a 96PE pulse




Example of a 91PE pulse







# 1165 PE distribution x=0mm y=0mm




Example of a 128PE pulse




Example of a 121PE pulse




Example of a 157PE pulse




Example of a 134PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 79PE pulse




Example of a 96PE pulse




Example of a 82PE pulse




Example of a 116PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 59PE pulse




Example of a 58PE pulse




Example of a 87PE pulse




Example of a 74PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 31PE pulse




Example of a 52PE pulse




Example of a 30PE pulse




Example of a 65PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 66PE pulse




Example of a 56PE pulse




Example of a 110PE pulse




Example of a 100PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 67PE pulse




Example of a 75PE pulse




Example of a 119PE pulse




Example of a 126PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 78PE pulse




Example of a 80PE pulse




Example of a 100PE pulse




Example of a 74PE pulse




# 1165 PE distribution x=0mm y=0mm




Example of a 95PE pulse



Example of a 118PE pulse



Example of a 92PE pulse



Example of a 85PE pulse

