




817 PE distribution x=2250mm y=25mm




Example of a 53PE pulse




Example of a 75PE pulse




Example of a 60PE pulse




Example of a 50PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 69PE pulse




Example of a 79PE pulse




Example of a 71PE pulse




Example of a 76PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 99PE pulse




Example of a 125PE pulse




Example of a 68PE pulse




Example of a 71PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 62PE pulse




Example of a 76PE pulse




Example of a 80PE pulse




Example of a 110PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 48PE pulse




Example of a 40PE pulse




Example of a 57PE pulse




Example of a 48PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 60PE pulse




Example of a 66PE pulse




Example of a 57PE pulse




Example of a 58PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 94PE pulse




Example of a 89PE pulse




Example of a 57PE pulse




Example of a 81PE pulse




817 PE distribution x=2250mm y=25mm




Example of a 50PE pulse



Example of a 48PE pulse



Example of a 73PE pulse



Example of a 68PE pulse

