




1254 PE distribution x=1750mm y=75mm




Example of a 60PE pulse




Example of a 98PE pulse




Example of a 74PE pulse




Example of a 89PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 83PE pulse




Example of a 61PE pulse




Example of a 78PE pulse




Example of a 58PE pulse




1254 PE distribution x=1750mm y=75mm




1254 PE distribution x=1750mm y=75mm




1254 PE distribution x=1750mm y=75mm




1254 PE distribution x=1750mm y=75mm




1254 PE distribution x=1750mm y=75mm




Example of a 35PE pulse




Example of a 313PE pulse




Example of a 54PE pulse




Example of a 68PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 309PE pulse




Example of a 262PE pulse




Example of a 76PE pulse




Example of a 51PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 81PE pulse




Example of a 113PE pulse




Example of a 94PE pulse




Example of a 92PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 97PE pulse




Example of a 85PE pulse




Example of a 101PE pulse




Example of a 65PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 64PE pulse




Example of a 87PE pulse




Example of a 80PE pulse




Example of a 77PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 79PE pulse




Example of a 79PE pulse




Example of a 70PE pulse




Example of a 66PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 273PE pulse




Example of a 335PE pulse




Example of a 142PE pulse




Example of a 159PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 117PE pulse




Example of a 96PE pulse




Example of a 112PE pulse




Example of a 99PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 50PE pulse




Example of a 46PE pulse




Example of a 63PE pulse




Example of a 65PE pulse




1254 PE distribution x=1750mm y=75mm




Example of a 285PE pulse



Example of a 292PE pulse



Example of a 68PE pulse



Example of a 68PE pulse

