




# 1183 PE distribution x=1000mm y=75mm




Example of a 142PE pulse




Example of a 125PE pulse




Example of a 168PE pulse




Example of a 199PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 102PE pulse




Example of a 197PE pulse




Example of a 176PE pulse




Example of a 146PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 171PE pulse




Example of a 139PE pulse




Example of a 136PE pulse




Example of a 206PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 218PE pulse




Example of a 213PE pulse




Example of a 223PE pulse




Example of a 224PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 30PE pulse




Example of a 20PE pulse




Example of a 32PE pulse




Example of a 20PE pulse




# 1183 PE distribution x=1000mm y=75mm




# 1183 PE distribution x=1000mm y=75mm




Example of a 46PE pulse




Example of a 34PE pulse




Example of a 26PE pulse




Example of a 24PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 142PE pulse




Example of a 176PE pulse



Example of a 139PE pulse




Example of a 150PE pulse







# 1183 PE distribution x=1000mm y=75mm




Example of a 224PE pulse




Example of a 224PE pulse




Example of a 36PE pulse




Example of a 52PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 249PE pulse




Example of a 235PE pulse




Example of a 207PE pulse




Example of a 211PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 162PE pulse




Example of a 134PE pulse




Example of a 141PE pulse




Example of a 181PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 109PE pulse




Example of a 136PE pulse




Example of a 180PE pulse




Example of a 177PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 127PE pulse




Example of a 139PE pulse




Example of a 154PE pulse




Example of a 110PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 156PE pulse




Example of a 161PE pulse




Example of a 141PE pulse




Example of a 124PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 32PE pulse




Example of a 21PE pulse




Example of a 31PE pulse




Example of a 50PE pulse




# 1183 PE distribution x=1000mm y=75mm




Example of a 23PE pulse



Example of a 25PE pulse



Example of a 144PE pulse



Example of a 53PE pulse

