




# 1338 PE distribution x=1000mm y=75mm




Example of a 130PE pulse




Example of a 104PE pulse




Example of a 75PE pulse




Example of a 75PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 93PE pulse




Example of a 74PE pulse




Example of a 104PE pulse




Example of a 97PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 58PE pulse




Example of a 65PE pulse




Example of a 59PE pulse




Example of a 79PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 63PE pulse




Example of a 63PE pulse




Example of a 58PE pulse




Example of a 58PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 68PE pulse




Example of a 69PE pulse




Example of a 67PE pulse




Example of a 54PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 67PE pulse




Example of a 59PE pulse




Example of a 49PE pulse




Example of a 43PE pulse




1338 PE distribution x=1000mm y=75mm




Example of a 163PE pulse




Example of a 150PE pulse




Example of a 53PE pulse




Example of a 71PE pulse




1338 PE distribution x=1000mm y=75mm




Example of a 35PE pulse




Example of a 69PE pulse



Example of a 60PE pulse




Example of a 61PE pulse







# 1338 PE distribution x=1000mm y=75mm




Example of a 107PE pulse




Example of a 74PE pulse




Example of a 60PE pulse




Example of a 51PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 57PE pulse




Example of a 63PE pulse




Example of a 62PE pulse




Example of a 76PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 54PE pulse




Example of a 54PE pulse




Example of a 38PE pulse




Example of a 58PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 98PE pulse




Example of a 55PE pulse




Example of a 58PE pulse




Example of a 49PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 63PE pulse




Example of a 59PE pulse




Example of a 53PE pulse




Example of a 46PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 59PE pulse




Example of a 40PE pulse




Example of a 48PE pulse




Example of a 31PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 100PE pulse




Example of a 28PE pulse




Example of a 38PE pulse




Example of a 69PE pulse




# 1338 PE distribution x=1000mm y=75mm




Example of a 23PE pulse



Example of a 43PE pulse



Example of a 40PE pulse



Example of a 211PE pulse

