




1265 PE distribution x=300mm y=25mm




Example of a 166PE pulse




Example of a 184PE pulse




Example of a 90PE pulse




Example of a 106PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 226PE pulse




Example of a 223PE pulse




Example of a 124PE pulse




Example of a 89PE pulse




1265 PE distribution x=300mm y=25mm




1265 PE distribution x=300mm y=25mm




1265 PE distribution x=300mm y=25mm




Example of a 21PE pulse




Example of a 27PE pulse




Example of a 22PE pulse




Example of a 22PE pulse




1265 PE distribution x=300mm y=25mm




1265 PE distribution x=300mm y=25mm




Example of a 94PE pulse




Example of a 69PE pulse




Example of a 80PE pulse




Example of a 78PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 130PE pulse




Example of a 128PE pulse




Example of a 101PE pulse




Example of a 358PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 99PE pulse




Example of a 121PE pulse




Example of a 84PE pulse




Example of a 72PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 132PE pulse




Example of a 141PE pulse




Example of a 64PE pulse




Example of a 50PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 114PE pulse




Example of a 121PE pulse




Example of a 98PE pulse




Example of a 86PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 39PE pulse




Example of a 50PE pulse




Example of a 35PE pulse




Example of a 38PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 134PE pulse




Example of a 125PE pulse




Example of a 88PE pulse




Example of a 77PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 121PE pulse




Example of a 86PE pulse




Example of a 109PE pulse




Example of a 85PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 65PE pulse




Example of a 58PE pulse




Example of a 55PE pulse




Example of a 45PE pulse




1265 PE distribution x=300mm y=25mm




Example of a 91PE pulse



Example of a 75PE pulse



Example of a 273PE pulse



Example of a 305PE pulse

