




# 1261 PE distribution x=1250mm y=25mm




Example of a 88PE pulse




Example of a 76PE pulse




Example of a 140PE pulse




Example of a 127PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 149PE pulse




Example of a 151PE pulse




Example of a 266PE pulse




Example of a 289PE pulse




1261 PE distribution x=1250mm y=25mm




1261 PE distribution x=1250mm y=25mm




# 1261 PE distribution x=1250mm y=25mm




Example of a 20PE pulse




Example of a 31PE pulse




Example of a 20PE pulse




Example of a 23PE pulse




1261 PE distribution x=1250mm y=25mm




1261 PE distribution x=1250mm y=25mm




Example of a 67PE pulse




Example of a 72PE pulse




Example of a 92PE pulse




Example of a 108PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 123PE pulse




Example of a 134PE pulse



Example of a 183PE pulse




Example of a 178PE pulse







1261 PE distribution x=1250mm y=25mm




Example of a 80PE pulse




Example of a 61PE pulse




Example of a 109PE pulse




Example of a 120PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 112PE pulse




Example of a 147PE pulse




Example of a 270PE pulse




Example of a 277PE pulse




1261 PE distribution x=1250mm y=25mm




Example of a 58PE pulse




Example of a 63PE pulse




Example of a 79PE pulse




Example of a 59PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 127PE pulse




Example of a 169PE pulse




Example of a 193PE pulse




Example of a 207PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 88PE pulse




Example of a 95PE pulse




Example of a 133PE pulse




Example of a 140PE pulse




# 1261 PE distribution x=1250mm y=25mm




Example of a 154PE pulse




Example of a 137PE pulse




Example of a 206PE pulse




Example of a 175PE pulse




1261 PE distribution x=1250mm y=25mm




Example of a 54PE pulse




Example of a 46PE pulse




Example of a 56PE pulse




Example of a 94PE pulse




1261 PE distribution x=1250mm y=25mm




Example of a 128PE pulse



Example of a 128PE pulse



Example of a 178PE pulse



Example of a 142PE pulse

