




1156 PE distribution x=1000mm y=25mm




Example of a 96PE pulse




Example of a 81PE pulse




Example of a 62PE pulse




Example of a 57PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 82PE pulse




Example of a 71PE pulse




Example of a 109PE pulse




Example of a 103PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 89PE pulse




Example of a 67PE pulse




Example of a 105PE pulse




Example of a 85PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 179PE pulse




Example of a 184PE pulse




Example of a 95PE pulse




Example of a 89PE pulse




1156 PE distribution x=1000mm y=25mm




1156 PE distribution x=1000mm y=25mm




1156 PE distribution x=1000mm y=25mm




Example of a 75PE pulse




Example of a 86PE pulse




Example of a 80PE pulse




Example of a 71PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 188PE pulse




Example of a 150PE pulse




Example of a 74PE pulse




Example of a 85PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 97PE pulse




Example of a 101PE pulse




Example of a 140PE pulse




Example of a 174PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 183PE pulse




Example of a 245PE pulse




Example of a 111PE pulse




Example of a 100PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 90PE pulse




Example of a 76PE pulse




Example of a 58PE pulse




Example of a 50PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 61PE pulse




Example of a 56PE pulse




Example of a 63PE pulse




Example of a 90PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 65PE pulse




Example of a 58PE pulse




Example of a 100PE pulse




Example of a 90PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 152PE pulse




Example of a 142PE pulse




Example of a 69PE pulse




Example of a 53PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 62PE pulse




Example of a 69PE pulse




Example of a 85PE pulse




Example of a 61PE pulse




1156 PE distribution x=1000mm y=25mm




Example of a 144PE pulse



Example of a 120PE pulse



Example of a 32PE pulse



Example of a 71PE pulse

