




1019 PE distribution x=5mm y=25mm




Example of a 57PE pulse




Example of a 52PE pulse




Example of a 75PE pulse




Example of a 60PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 221PE pulse




Example of a 185PE pulse




Example of a 76PE pulse




Example of a 43PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 52PE pulse




Example of a 36PE pulse




Example of a 64PE pulse




Example of a 69PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 192PE pulse




Example of a 198PE pulse




Example of a 59PE pulse




Example of a 34PE pulse




1019 PE distribution x=5mm y=25mm




1019 PE distribution x=5mm y=25mm




1019 PE distribution x=5mm y=25mm




Example of a 109PE pulse




Example of a 69PE pulse




Example of a 66PE pulse




Example of a 69PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 76PE pulse




Example of a 129PE pulse




Example of a 24PE pulse




Example of a 22PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 30PE pulse




Example of a 35PE pulse




Example of a 50PE pulse




Example of a 38PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 115PE pulse




Example of a 125PE pulse




Example of a 154PE pulse




Example of a 37PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 28PE pulse




Example of a 26PE pulse




Example of a 38PE pulse




Example of a 38PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 59PE pulse




Example of a 65PE pulse




Example of a 145PE pulse




Example of a 142PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 25PE pulse




Example of a 31PE pulse




Example of a 41PE pulse




Example of a 38PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 177PE pulse




Example of a 135PE pulse




Example of a 91PE pulse




Example of a 106PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 234PE pulse




Example of a 231PE pulse




Example of a 21PE pulse




Example of a 20PE pulse




1019 PE distribution x=5mm y=25mm




Example of a 113PE pulse



Example of a 26PE pulse



Example of a 32PE pulse



Example of a 39PE pulse

