




1286 PE distribution x=300mm y=75mm




Example of a 214PE pulse




Example of a 258PE pulse




Example of a 107PE pulse




Example of a 78PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 114PE pulse




Example of a 103PE pulse




Example of a 141PE pulse




Example of a 120PE pulse




1286 PE distribution x=300mm y=75mm




1286 PE distribution x=300mm y=75mm




1286 PE distribution x=300mm y=75mm




1286 PE distribution x=300mm y=75mm




1286 PE distribution x=300mm y=75mm




Example of a 147PE pulse




Example of a 159PE pulse




Example of a 228PE pulse




Example of a 150PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 97PE pulse




Example of a 88PE pulse




Example of a 89PE pulse




Example of a 80PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 173PE pulse




Example of a 158PE pulse




Example of a 68PE pulse




Example of a 49PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 82PE pulse




Example of a 70PE pulse




Example of a 90PE pulse




Example of a 60PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 87PE pulse




Example of a 28PE pulse




Example of a 28PE pulse




Example of a 277PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 52PE pulse




Example of a 43PE pulse




Example of a 77PE pulse




Example of a 48PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 42PE pulse




Example of a 48PE pulse




Example of a 192PE pulse




Example of a 199PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 83PE pulse




Example of a 70PE pulse




Example of a 105PE pulse




Example of a 73PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 93PE pulse




Example of a 107PE pulse




Example of a 133PE pulse




Example of a 129PE pulse




1286 PE distribution x=300mm y=75mm




Example of a 81PE pulse



Example of a 59PE pulse



Example of a 61PE pulse



Example of a 69PE pulse

