




# 707 PE distribution x=90mm y=25mm




Example of a 64PE pulse




Example of a 44PE pulse




Example of a 44PE pulse




Example of a 31PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 27PE pulse




Example of a 66PE pulse




Example of a 42PE pulse




Example of a 68PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 50PE pulse




Example of a 34PE pulse




Example of a 41PE pulse




Example of a 42PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 34PE pulse




Example of a 45PE pulse




Example of a 42PE pulse




Example of a 34PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 52PE pulse




Example of a 35PE pulse




Example of a 99PE pulse




Example of a 79PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 168PE pulse




Example of a 149PE pulse




Example of a 147PE pulse




Example of a 162PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 161PE pulse




Example of a 147PE pulse




Example of a 27PE pulse




Example of a 28PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 41PE pulse




Example of a 44PE pulse



Example of a 58PE pulse




Example of a 52PE pulse







# 707 PE distribution x=90mm y=25mm




Example of a 90PE pulse




Example of a 90PE pulse




Example of a 88PE pulse




Example of a 92PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 82PE pulse




Example of a 134PE pulse








Example of a 94PE pulse




Example of a 101PE pulse




# 707 PE distribution x=90mm y=25mm




# 707 PE distribution x=90mm y=25mm




Example of a 60PE pulse




Example of a 67PE pulse




Example of a 76PE pulse




Example of a 78PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 87PE pulse




Example of a 82PE pulse




Example of a 150PE pulse




Example of a 154PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 94PE pulse




Example of a 241PE pulse




Example of a 207PE pulse




Example of a 230PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 224PE pulse




Example of a 27PE pulse




Example of a 39PE pulse




Example of a 24PE pulse




# 707 PE distribution x=90mm y=25mm




Example of a 49PE pulse



Example of a 68PE pulse



Example of a 73PE pulse



Example of a 73PE pulse

