




# 825 PE distribution x=1750mm y=75mm




Example of a 45PE pulse




Example of a 39PE pulse




Example of a 64PE pulse




Example of a 53PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 67PE pulse




Example of a 79PE pulse




Example of a 75PE pulse




Example of a 48PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 74PE pulse




Example of a 51PE pulse




Example of a 76PE pulse




Example of a 92PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 104PE pulse




Example of a 95PE pulse




Example of a 60PE pulse




Example of a 83PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 43PE pulse




Example of a 39PE pulse




Example of a 54PE pulse




Example of a 40PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 77PE pulse




Example of a 68PE pulse




Example of a 66PE pulse




Example of a 65PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 61PE pulse




Example of a 53PE pulse




Example of a 78PE pulse




Example of a 63PE pulse




# 825 PE distribution x=1750mm y=75mm




Example of a 88PE pulse



Example of a 116PE pulse



Example of a 76PE pulse



Example of a 57PE pulse

