




1014 PE distribution x=100mm y=75mm




Example of a 119PE pulse




Example of a 101PE pulse




Example of a 88PE pulse




Example of a 108PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 153PE pulse




Example of a 113PE pulse




Example of a 147PE pulse




Example of a 116PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 77PE pulse




Example of a 67PE pulse




Example of a 70PE pulse




Example of a 94PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 182PE pulse




Example of a 146PE pulse




Example of a 94PE pulse




Example of a 91PE pulse




1014 PE distribution x=100mm y=75mm




1014 PE distribution x=100mm y=75mm




1014 PE distribution x=100mm y=75mm




Example of a 54PE pulse




Example of a 42PE pulse




Example of a 152PE pulse




Example of a 121PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 155PE pulse




Example of a 128PE pulse




Example of a 58PE pulse




Example of a 94PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 246PE pulse




Example of a 255PE pulse




Example of a 238PE pulse




Example of a 220PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 56PE pulse




Example of a 65PE pulse




Example of a 75PE pulse




Example of a 54PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 213PE pulse




Example of a 41PE pulse




Example of a 37PE pulse




Example of a 243PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 85PE pulse




Example of a 90PE pulse




Example of a 44PE pulse




Example of a 50PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 252PE pulse




Example of a 75PE pulse




Example of a 75PE pulse




Example of a 20PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 49PE pulse




Example of a 41PE pulse




Example of a 70PE pulse




Example of a 54PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 31PE pulse




Example of a 26PE pulse




Example of a 108PE pulse




Example of a 81PE pulse




1014 PE distribution x=100mm y=75mm




Example of a 72PE pulse



Example of a 64PE pulse



Example of a 26PE pulse



Example of a 34PE pulse

