




798 PE distribution x=200mm y=75mm




Example of a 34PE pulse




Example of a 38PE pulse




Example of a 31PE pulse




Example of a 40PE pulse




798 PE distribution x=200mm y=75mm




Example of a 43PE pulse




Example of a 55PE pulse




Example of a 60PE pulse




Example of a 61PE pulse




798 PE distribution x=200mm y=75mm




Example of a 48PE pulse




Example of a 50PE pulse




Example of a 92PE pulse




Example of a 95PE pulse




798 PE distribution x=200mm y=75mm




Example of a 58PE pulse




Example of a 57PE pulse




Example of a 106PE pulse




Example of a 112PE pulse




798 PE distribution x=200mm y=75mm




Example of a 55PE pulse




Example of a 53PE pulse




Example of a 64PE pulse




Example of a 73PE pulse




798 PE distribution x=200mm y=75mm




Example of a 68PE pulse




Example of a 71PE pulse




Example of a 142PE pulse




Example of a 122PE pulse




798 PE distribution x=200mm y=75mm




Example of a 81PE pulse




Example of a 86PE pulse




Example of a 138PE pulse




Example of a 136PE pulse




798 PE distribution x=200mm y=75mm




Example of a 137PE pulse



Example of a 129PE pulse



Example of a 177PE pulse



Example of a 182PE pulse

