




711 PE distribution x=50mm y=25mm




Example of a 53PE pulse




Example of a 47PE pulse




Example of a 55PE pulse




Example of a 55PE pulse




711 PE distribution x=50mm y=25mm




Example of a 80PE pulse




Example of a 103PE pulse




Example of a 99PE pulse




Example of a 143PE pulse




711 PE distribution x=50mm y=25mm




Example of a 48PE pulse




Example of a 30PE pulse




Example of a 41PE pulse




Example of a 42PE pulse




711 PE distribution x=50mm y=25mm




Example of a 35PE pulse




Example of a 45PE pulse




Example of a 99PE pulse




Example of a 84PE pulse




711 PE distribution x=50mm y=25mm




Example of a 44PE pulse




Example of a 35PE pulse




Example of a 47PE pulse




Example of a 60PE pulse




711 PE distribution x=50mm y=25mm




Example of a 92PE pulse




Example of a 121PE pulse




Example of a 90PE pulse




Example of a 122PE pulse




711 PE distribution x=50mm y=25mm




Example of a 21PE pulse




Example of a 27PE pulse




Example of a 46PE pulse




Example of a 39PE pulse




711 PE distribution x=50mm y=25mm




Example of a 26PE pulse




Example of a 31PE pulse




Example of a 73PE pulse




Example of a 82PE pulse




711 PE distribution x=50mm y=25mm




Example of a 94PE pulse




Example of a 74PE pulse




Example of a 110PE pulse




Example of a 141PE pulse




711 PE distribution x=50mm y=25mm




Example of a 147PE pulse




Example of a 158PE pulse




Example of a 140PE pulse




Example of a 134PE pulse




711 PE distribution x=50mm y=25mm




Example of a 86PE pulse




Example of a 68PE pulse




Example of a 76PE pulse




Example of a 85PE pulse




711 PE distribution x=50mm y=25mm




Example of a 66PE pulse




Example of a 74PE pulse




Example of a 73PE pulse




Example of a 98PE pulse




711 PE distribution x=50mm y=25mm




Example of a 66PE pulse




Example of a 78PE pulse




Example of a 112PE pulse




Example of a 105PE pulse




711 PE distribution x=50mm y=25mm




Example of a 125PE pulse




Example of a 165PE pulse




Example of a 74PE pulse




Example of a 111PE pulse




711 PE distribution x=50mm y=25mm




Example of a 26PE pulse




Example of a 42PE pulse




Example of a 62PE pulse




Example of a 86PE pulse




711 PE distribution x=50mm y=25mm




Example of a 42PE pulse



Example of a 39PE pulse



Example of a 105PE pulse



Example of a 130PE pulse

