




838 PE distribution x=300mm y=25mm




Example of a 37PE pulse




Example of a 27PE pulse




Example of a 36PE pulse




Example of a 54PE pulse




838 PE distribution x=300mm y=25mm




Example of a 47PE pulse




Example of a 68PE pulse




Example of a 32PE pulse




Example of a 46PE pulse




838 PE distribution x=300mm y=25mm




Example of a 53PE pulse




Example of a 50PE pulse




Example of a 40PE pulse




Example of a 40PE pulse




838 PE distribution x=300mm y=25mm




Example of a 45PE pulse




Example of a 54PE pulse




Example of a 95PE pulse




Example of a 127PE pulse




838 PE distribution x=300mm y=25mm




Example of a 46PE pulse




Example of a 59PE pulse




Example of a 52PE pulse




Example of a 58PE pulse




838 PE distribution x=300mm y=25mm




Example of a 76PE pulse




Example of a 97PE pulse




Example of a 36PE pulse




Example of a 62PE pulse




838 PE distribution x=300mm y=25mm




Example of a 91PE pulse




Example of a 92PE pulse




Example of a 53PE pulse




Example of a 54PE pulse




838 PE distribution x=300mm y=25mm




Example of a 91PE pulse



Example of a 89PE pulse



Example of a 120PE pulse



Example of a 155PE pulse

