




1336 PE distribution x=1250mm y=75mm




Example of a 253PE pulse




Example of a 234PE pulse




Example of a 156PE pulse




Example of a 157PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 112PE pulse




Example of a 105PE pulse




Example of a 111PE pulse




Example of a 93PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 192PE pulse




Example of a 180PE pulse




Example of a 145PE pulse




Example of a 115PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 75PE pulse




Example of a 65PE pulse




Example of a 57PE pulse




Example of a 40PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 36PE pulse




Example of a 36PE pulse




Example of a 125PE pulse




Example of a 130PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 55PE pulse




Example of a 56PE pulse




Example of a 88PE pulse




Example of a 60PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 71PE pulse




Example of a 61PE pulse




Example of a 43PE pulse




Example of a 41PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 59PE pulse




Example of a 59PE pulse




Example of a 47PE pulse




Example of a 73PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 230PE pulse




Example of a 238PE pulse




Example of a 179PE pulse




Example of a 159PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 111PE pulse




Example of a 81PE pulse




Example of a 93PE pulse




Example of a 89PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 172PE pulse




Example of a 157PE pulse




Example of a 160PE pulse




Example of a 131PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 74PE pulse




Example of a 48PE pulse




Example of a 44PE pulse




Example of a 63PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 28PE pulse




Example of a 25PE pulse




Example of a 167PE pulse




Example of a 115PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 55PE pulse




Example of a 51PE pulse




Example of a 64PE pulse




Example of a 61PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 108PE pulse




Example of a 59PE pulse




Example of a 26PE pulse




Example of a 29PE pulse




1336 PE distribution x=1250mm y=75mm




Example of a 39PE pulse



Example of a 32PE pulse



Example of a 95PE pulse



Example of a 41PE pulse

