




1149 PE distribution x=1000mm y=75mm




Example of a 28PE pulse




Example of a 50PE pulse




Example of a 251PE pulse




Example of a 260PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 64PE pulse




Example of a 52PE pulse




Example of a 55PE pulse




Example of a 37PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 41PE pulse




Example of a 70PE pulse




Example of a 190PE pulse




Example of a 211PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 98PE pulse




Example of a 91PE pulse




Example of a 63PE pulse




Example of a 54PE pulse




1149 PE distribution x=1000mm y=75mm




1149 PE distribution x=1000mm y=75mm




1149 PE distribution x=1000mm y=75mm




Example of a 50PE pulse




Example of a 27PE pulse




Example of a 162PE pulse




Example of a 179PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 71PE pulse




Example of a 76PE pulse




Example of a 82PE pulse




Example of a 87PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 48PE pulse




Example of a 70PE pulse




Example of a 216PE pulse




Example of a 215PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 62PE pulse




Example of a 68PE pulse




Example of a 128PE pulse




Example of a 121PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 44PE pulse




Example of a 124PE pulse




Example of a 210PE pulse




Example of a 454PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 41PE pulse




Example of a 40PE pulse




Example of a 39PE pulse




Example of a 38PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 48PE pulse




Example of a 74PE pulse




Example of a 167PE pulse




Example of a 167PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 91PE pulse




Example of a 71PE pulse




Example of a 69PE pulse




Example of a 65PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 60PE pulse




Example of a 27PE pulse




Example of a 125PE pulse




Example of a 184PE pulse




1149 PE distribution x=1000mm y=75mm




Example of a 85PE pulse



Example of a 74PE pulse



Example of a 88PE pulse



Example of a 77PE pulse

