




1009 PE distribution x=1000mm y=75mm




Example of a 278PE pulse




Example of a 267PE pulse




Example of a 174PE pulse




Example of a 210PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 105PE pulse




Example of a 99PE pulse




Example of a 104PE pulse




Example of a 93PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 124PE pulse




Example of a 126PE pulse




Example of a 86PE pulse




Example of a 66PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 92PE pulse




Example of a 92PE pulse




Example of a 57PE pulse




Example of a 69PE pulse




1009 PE distribution x=1000mm y=75mm




1009 PE distribution x=1000mm y=75mm




1009 PE distribution x=1000mm y=75mm




Example of a 100PE pulse




Example of a 99PE pulse




Example of a 103PE pulse




Example of a 126PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 70PE pulse




Example of a 56PE pulse




Example of a 74PE pulse




Example of a 94PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 253PE pulse




Example of a 256PE pulse




Example of a 156PE pulse




Example of a 182PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 76PE pulse




Example of a 72PE pulse




Example of a 69PE pulse




Example of a 96PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 94PE pulse




Example of a 115PE pulse




Example of a 56PE pulse




Example of a 46PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 86PE pulse




Example of a 75PE pulse




Example of a 54PE pulse




Example of a 51PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 133PE pulse




Example of a 140PE pulse




Example of a 154PE pulse




Example of a 158PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 76PE pulse




Example of a 61PE pulse




Example of a 89PE pulse




Example of a 66PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 97PE pulse




Example of a 119PE pulse




Example of a 81PE pulse




Example of a 126PE pulse




1009 PE distribution x=1000mm y=75mm




Example of a 66PE pulse



Example of a 47PE pulse



Example of a 46PE pulse



Example of a 47PE pulse

