




1024 PE distribution x=200mm y=25mm




Example of a 117PE pulse




Example of a 105PE pulse




Example of a 110PE pulse




Example of a 107PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 130PE pulse




Example of a 105PE pulse




Example of a 101PE pulse




Example of a 115PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 83PE pulse




Example of a 93PE pulse




Example of a 129PE pulse




Example of a 119PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 89PE pulse




Example of a 74PE pulse




Example of a 88PE pulse




Example of a 80PE pulse




1024 PE distribution x=200mm y=25mm




1024 PE distribution x=200mm y=25mm




1024 PE distribution x=200mm y=25mm




Example of a 240PE pulse




Example of a 209PE pulse




Example of a 153PE pulse




Example of a 152PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 299PE pulse




Example of a 323PE pulse




Example of a 28PE pulse




Example of a 53PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 69PE pulse




Example of a 72PE pulse




Example of a 67PE pulse




Example of a 70PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 56PE pulse




Example of a 70PE pulse




Example of a 228PE pulse




Example of a 260PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 56PE pulse




Example of a 53PE pulse




Example of a 46PE pulse




Example of a 57PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 67PE pulse




Example of a 42PE pulse




Example of a 245PE pulse




Example of a 203PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 71PE pulse




Example of a 74PE pulse




Example of a 59PE pulse




Example of a 65PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 60PE pulse




Example of a 39PE pulse




Example of a 218PE pulse




Example of a 200PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 63PE pulse




Example of a 49PE pulse




Example of a 48PE pulse




Example of a 53PE pulse




1024 PE distribution x=200mm y=25mm




Example of a 132PE pulse



Example of a 126PE pulse



Example of a 20PE pulse



Example of a 258PE pulse

