




# 1026 PE distribution x=500mm y=25mm




Example of a 118PE pulse




Example of a 117PE pulse




Example of a 101PE pulse




Example of a 96PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 109PE pulse




Example of a 160PE pulse




Example of a 131PE pulse




Example of a 90PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 78PE pulse




Example of a 75PE pulse




Example of a 162PE pulse




Example of a 149PE pulse




# 1026 PE distribution x=500mm y=25mm




## Example of a 76PE pulse




## Example of a 76PE pulse




## Example of a 82PE pulse




## Example of a 74PE pulse




1026 PE distribution x=500mm y=25mm




1026 PE distribution x=500mm y=25mm




# 1026 PE distribution x=500mm y=25mm




Example of a 144PE pulse




Example of a 177PE pulse




Example of a 178PE pulse




Example of a 111PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 239PE pulse




Example of a 64PE pulse



Example of a 80PE pulse




Example of a 71PE pulse







# 1026 PE distribution x=500mm y=25mm




Example of a 72PE pulse




Example of a 76PE pulse




Example of a 60PE pulse




Example of a 67PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 76PE pulse




Example of a 97PE pulse




Example of a 69PE pulse




Example of a 49PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 59PE pulse




Example of a 59PE pulse




Example of a 107PE pulse




Example of a 98PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 42PE pulse




Example of a 54PE pulse




Example of a 51PE pulse




Example of a 40PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 53PE pulse




Example of a 80PE pulse




Example of a 51PE pulse




Example of a 74PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 61PE pulse




Example of a 69PE pulse




Example of a 107PE pulse




Example of a 86PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 51PE pulse




Example of a 58PE pulse




Example of a 41PE pulse




Example of a 46PE pulse




# 1026 PE distribution x=500mm y=25mm




Example of a 58PE pulse



Example of a 47PE pulse



Example of a 48PE pulse



Example of a 33PE pulse

