




# 1252 PE distribution x=1250mm y=75mm




Example of a 73PE pulse




Example of a 85PE pulse




Example of a 32PE pulse




Example of a 30PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 123PE pulse




Example of a 87PE pulse




Example of a 85PE pulse




Example of a 75PE pulse




1252 PE distribution x=1250mm y=75mm




1252 PE distribution x=1250mm y=75mm




# 1252 PE distribution x=1250mm y=75mm




Example of a 20PE pulse




Example of a 21PE pulse




Example of a 22PE pulse




Example of a 21PE pulse




1252 PE distribution x=1250mm y=75mm




# 1252 PE distribution x=1250mm y=75mm




Example of a 164PE pulse




Example of a 201PE pulse




Example of a 119PE pulse




Example of a 121PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 76PE pulse




Example of a 58PE pulse



Example of a 61PE pulse




Example of a 62PE pulse







# 1252 PE distribution x=1250mm y=75mm




Example of a 70PE pulse




Example of a 65PE pulse




Example of a 34PE pulse




Example of a 27PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 90PE pulse




Example of a 88PE pulse




Example of a 86PE pulse




Example of a 78PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 61PE pulse




Example of a 55PE pulse




Example of a 21PE pulse




Example of a 22PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 107PE pulse




Example of a 87PE pulse




Example of a 84PE pulse




Example of a 119PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 276PE pulse




Example of a 267PE pulse




Example of a 291PE pulse




Example of a 259PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 100PE pulse




Example of a 100PE pulse




Example of a 99PE pulse




Example of a 78PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 155PE pulse




Example of a 191PE pulse




Example of a 99PE pulse




Example of a 110PE pulse




# 1252 PE distribution x=1250mm y=75mm




Example of a 67PE pulse



Example of a 65PE pulse



Example of a 67PE pulse



Example of a 76PE pulse

