




804 PE distribution x=750mm y=25mm




Example of a 49PE pulse




Example of a 43PE pulse




Example of a 55PE pulse




Example of a 43PE pulse




804 PE distribution x=750mm y=25mm




Example of a 42PE pulse




Example of a 42PE pulse




Example of a 43PE pulse




Example of a 59PE pulse




804 PE distribution x=750mm y=25mm




Example of a 57PE pulse




Example of a 75PE pulse




Example of a 48PE pulse




Example of a 38PE pulse




804 PE distribution x=750mm y=25mm




Example of a 74PE pulse




Example of a 76PE pulse




Example of a 135PE pulse




Example of a 126PE pulse




804 PE distribution x=750mm y=25mm




Example of a 59PE pulse




Example of a 72PE pulse




Example of a 43PE pulse




Example of a 75PE pulse




804 PE distribution x=750mm y=25mm




Example of a 65PE pulse




Example of a 60PE pulse




Example of a 72PE pulse




Example of a 74PE pulse




804 PE distribution x=750mm y=25mm




Example of a 72PE pulse




Example of a 91PE pulse




Example of a 62PE pulse




Example of a 59PE pulse




804 PE distribution x=750mm y=25mm




Example of a 63PE pulse



Example of a 89PE pulse



Example of a 180PE pulse



Example of a 197PE pulse

