




# 1279 PE distribution x=20mm y=75mm




Example of a 94PE pulse




Example of a 121PE pulse




Example of a 139PE pulse




Example of a 128PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 91PE pulse




Example of a 72PE pulse




Example of a 65PE pulse




Example of a 59PE pulse




# 1279 PE distribution x=20mm y=75mm




# 1279 PE distribution x=20mm y=75mm




# 1279 PE distribution x=20mm y=75mm




Example of a 24PE pulse




Example of a 20PE pulse




Example of a 23PE pulse




Example of a 30PE pulse




# 1279 PE distribution x=20mm y=75mm




# 1279 PE distribution x=20mm y=75mm




Example of a 225PE pulse




Example of a 195PE pulse




Example of a 80PE pulse




Example of a 71PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 89PE pulse




Example of a 91PE pulse



Example of a 86PE pulse




Example of a 95PE pulse







# 1279 PE distribution x=20mm y=75mm




Example of a 60PE pulse




Example of a 49PE pulse




Example of a 97PE pulse




Example of a 78PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 35PE pulse




Example of a 26PE pulse




Example of a 27PE pulse




Example of a 30PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 117PE pulse




Example of a 127PE pulse




Example of a 60PE pulse




Example of a 34PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 27PE pulse




Example of a 25PE pulse




Example of a 23PE pulse




Example of a 23PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 267PE pulse




Example of a 303PE pulse




Example of a 37PE pulse




Example of a 33PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 56PE pulse




Example of a 41PE pulse




Example of a 38PE pulse




Example of a 23PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 128PE pulse




Example of a 86PE pulse




Example of a 37PE pulse




Example of a 35PE pulse




# 1279 PE distribution x=20mm y=75mm




Example of a 52PE pulse



Example of a 57PE pulse



Example of a 41PE pulse



Example of a 62PE pulse

