




# 839 PE distribution x=200mm y=25mm




Example of a 33PE pulse




Example of a 37PE pulse




Example of a 30PE pulse




Example of a 46PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 54PE pulse




Example of a 59PE pulse




Example of a 36PE pulse




Example of a 47PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 43PE pulse




Example of a 53PE pulse




Example of a 45PE pulse




Example of a 44PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 51PE pulse




Example of a 51PE pulse




Example of a 52PE pulse




Example of a 50PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 82PE pulse




Example of a 80PE pulse




Example of a 74PE pulse




Example of a 71PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 114PE pulse




Example of a 81PE pulse




Example of a 88PE pulse




Example of a 104PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 82PE pulse




Example of a 97PE pulse




Example of a 87PE pulse




Example of a 84PE pulse




# 839 PE distribution x=200mm y=25mm




Example of a 111PE pulse



Example of a 110PE pulse



Example of a 85PE pulse



Example of a 121PE pulse

