




# 1274 PE distribution x=5mm y=25mm




Example of a 53PE pulse




Example of a 70PE pulse




Example of a 42PE pulse




Example of a 57PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 30PE pulse




Example of a 36PE pulse




Example of a 29PE pulse




Example of a 26PE pulse




# 1274 PE distribution x=5mm y=25mm




# 1274 PE distribution x=5mm y=25mm




# 1274 PE distribution x=5mm y=25mm




Example of a 21PE pulse




Example of a 22PE pulse




Example of a 25PE pulse




# 1274 PE distribution x=5mm y=25mm




# 1274 PE distribution x=5mm y=25mm




Example of a 345PE pulse




Example of a 335PE pulse




Example of a 28PE pulse




Example of a 29PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 159PE pulse




Example of a 151PE pulse



Example of a 120PE pulse




Example of a 108PE pulse







# 1274 PE distribution x=5mm y=25mm




Example of a 25PE pulse




Example of a 29PE pulse




Example of a 30PE pulse




Example of a 20PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 96PE pulse




Example of a 73PE pulse




Example of a 25PE pulse




Example of a 20PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 35PE pulse




Example of a 24PE pulse




Example of a 36PE pulse




Example of a 43PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 92PE pulse




Example of a 117PE pulse




Example of a 42PE pulse




Example of a 75PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 45PE pulse




Example of a 61PE pulse




Example of a 68PE pulse




Example of a 99PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 69PE pulse




Example of a 53PE pulse




Example of a 66PE pulse




Example of a 71PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 29PE pulse




Example of a 35PE pulse




Example of a 225PE pulse




Example of a 211PE pulse




# 1274 PE distribution x=5mm y=25mm




Example of a 89PE pulse



Example of a 109PE pulse



Example of a 71PE pulse



Example of a 58PE pulse

