




1332 PE distribution x=2250mm y=25mm




Example of a 78PE pulse




Example of a 80PE pulse




Example of a 61PE pulse




Example of a 68PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 74PE pulse




Example of a 51PE pulse




Example of a 68PE pulse




Example of a 60PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 43PE pulse




Example of a 32PE pulse




Example of a 48PE pulse




Example of a 53PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 40PE pulse




Example of a 34PE pulse




Example of a 37PE pulse




Example of a 35PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 52PE pulse




Example of a 68PE pulse




Example of a 67PE pulse




Example of a 52PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 79PE pulse




Example of a 70PE pulse




Example of a 44PE pulse




Example of a 45PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 47PE pulse




Example of a 55PE pulse




Example of a 43PE pulse




Example of a 52PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 72PE pulse




Example of a 78PE pulse




Example of a 26PE pulse




Example of a 49PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 89PE pulse




Example of a 104PE pulse




Example of a 87PE pulse




Example of a 83PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 75PE pulse




Example of a 75PE pulse




Example of a 128PE pulse




Example of a 98PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 67PE pulse




Example of a 66PE pulse




Example of a 57PE pulse




Example of a 51PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 42PE pulse




Example of a 32PE pulse




Example of a 61PE pulse




Example of a 70PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 63PE pulse




Example of a 61PE pulse




Example of a 87PE pulse




Example of a 65PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 93PE pulse




Example of a 113PE pulse




Example of a 81PE pulse




Example of a 55PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 24PE pulse




Example of a 43PE pulse




Example of a 44PE pulse




Example of a 43PE pulse




1332 PE distribution x=2250mm y=25mm




Example of a 84PE pulse



Example of a 75PE pulse



Example of a 70PE pulse



Example of a 40PE pulse

