




832 PE distribution x=1000mm y=75mm




Example of a 34PE pulse




Example of a 34PE pulse




Example of a 48PE pulse




Example of a 32PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 32PE pulse




Example of a 36PE pulse




Example of a 55PE pulse




Example of a 57PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 39PE pulse




Example of a 48PE pulse




Example of a 70PE pulse




Example of a 81PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 39PE pulse




Example of a 52PE pulse




Example of a 87PE pulse




Example of a 71PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 27PE pulse




Example of a 47PE pulse




Example of a 53PE pulse




Example of a 50PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 47PE pulse




Example of a 70PE pulse




Example of a 71PE pulse




Example of a 75PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 58PE pulse




Example of a 66PE pulse




Example of a 72PE pulse




Example of a 63PE pulse




832 PE distribution x=1000mm y=75mm




Example of a 66PE pulse



Example of a 54PE pulse



Example of a 94PE pulse



Example of a 88PE pulse

