




1335 PE distribution x=1500mm y=75mm




Example of a 66PE pulse




Example of a 69PE pulse




Example of a 88PE pulse




Example of a 80PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 73PE pulse




Example of a 74PE pulse




Example of a 134PE pulse




Example of a 127PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 65PE pulse




Example of a 46PE pulse




Example of a 68PE pulse




Example of a 58PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 55PE pulse




Example of a 54PE pulse




Example of a 57PE pulse




Example of a 39PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 35PE pulse




Example of a 60PE pulse




Example of a 59PE pulse




Example of a 291PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 55PE pulse




Example of a 45PE pulse




Example of a 82PE pulse




Example of a 70PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 70PE pulse




Example of a 38PE pulse




Example of a 69PE pulse




Example of a 64PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 36PE pulse




Example of a 59PE pulse




Example of a 44PE pulse




Example of a 66PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 83PE pulse




Example of a 50PE pulse




Example of a 97PE pulse




Example of a 63PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 65PE pulse




Example of a 53PE pulse




Example of a 139PE pulse




Example of a 120PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 38PE pulse




Example of a 73PE pulse




Example of a 54PE pulse




Example of a 300PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 51PE pulse




Example of a 59PE pulse




Example of a 55PE pulse




Example of a 49PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 48PE pulse




Example of a 30PE pulse




Example of a 73PE pulse




Example of a 61PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 50PE pulse




Example of a 48PE pulse




Example of a 63PE pulse




Example of a 75PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 40PE pulse




Example of a 26PE pulse




Example of a 45PE pulse




Example of a 53PE pulse




1335 PE distribution x=1500mm y=75mm




Example of a 54PE pulse



Example of a 49PE pulse



Example of a 35PE pulse



Example of a 30PE pulse

