




1015 PE distribution x=50mm y=75mm




Example of a 95PE pulse




Example of a 92PE pulse




Example of a 55PE pulse




Example of a 63PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 119PE pulse




Example of a 80PE pulse




Example of a 108PE pulse




Example of a 141PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 76PE pulse




Example of a 64PE pulse




Example of a 41PE pulse




Example of a 65PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 121PE pulse




Example of a 101PE pulse




Example of a 92PE pulse




Example of a 124PE pulse




1015 PE distribution x=50mm y=75mm




1015 PE distribution x=50mm y=75mm




1015 PE distribution x=50mm y=75mm




Example of a 51PE pulse




Example of a 42PE pulse




Example of a 78PE pulse




Example of a 50PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 94PE pulse




Example of a 66PE pulse




Example of a 62PE pulse




Example of a 83PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 69PE pulse




Example of a 51PE pulse




Example of a 102PE pulse




Example of a 90PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 52PE pulse




Example of a 29PE pulse




Example of a 65PE pulse




Example of a 63PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 47PE pulse




Example of a 38PE pulse




Example of a 90PE pulse




Example of a 94PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 51PE pulse




Example of a 43PE pulse




Example of a 51PE pulse




Example of a 39PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 40PE pulse




Example of a 39PE pulse




Example of a 105PE pulse




Example of a 113PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 67PE pulse




Example of a 34PE pulse




Example of a 41PE pulse




Example of a 46PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 31PE pulse




Example of a 38PE pulse




Example of a 39PE pulse




Example of a 28PE pulse




1015 PE distribution x=50mm y=75mm




Example of a 49PE pulse



Example of a 29PE pulse



Example of a 32PE pulse



Example of a 43PE pulse

