




# 813 PE distribution x=1750mm y=25mm




Example of a 45PE pulse




Example of a 52PE pulse




Example of a 50PE pulse




Example of a 61PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 56PE pulse




Example of a 59PE pulse




Example of a 70PE pulse




Example of a 51PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 107PE pulse




Example of a 109PE pulse




Example of a 123PE pulse




Example of a 155PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 67PE pulse




Example of a 67PE pulse




Example of a 137PE pulse




Example of a 168PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 41PE pulse




Example of a 48PE pulse




Example of a 35PE pulse




Example of a 40PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 60PE pulse




Example of a 71PE pulse




Example of a 54PE pulse




Example of a 53PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 97PE pulse




Example of a 101PE pulse




Example of a 109PE pulse




Example of a 118PE pulse




# 813 PE distribution x=1750mm y=25mm




Example of a 70PE pulse



Example of a 70PE pulse



Example of a 115PE pulse



Example of a 147PE pulse

