




# 1176 PE distribution x=1000mm y=75mm




Example of a 71PE pulse




Example of a 61PE pulse




Example of a 140PE pulse




Example of a 136PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 147PE pulse




Example of a 131PE pulse




Example of a 138PE pulse




Example of a 151PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 186PE pulse




Example of a 186PE pulse




Example of a 107PE pulse




Example of a 146PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 148PE pulse




Example of a 131PE pulse




Example of a 236PE pulse




Example of a 200PE pulse




1176 PE distribution x=1000mm y=75mm




1176 PE distribution x=1000mm y=75mm




# 1176 PE distribution x=1000mm y=75mm




Example of a 102PE pulse




Example of a 109PE pulse




Example of a 146PE pulse




Example of a 134PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 150PE pulse




Example of a 159PE pulse



Example of a 134PE pulse




Example of a 149PE pulse







# 1176 PE distribution x=1000mm y=75mm




Example of a 107PE pulse




Example of a 108PE pulse




Example of a 217PE pulse




Example of a 240PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 226PE pulse




Example of a 192PE pulse




Example of a 181PE pulse




Example of a 198PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 39PE pulse




Example of a 38PE pulse




Example of a 118PE pulse




Example of a 100PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 106PE pulse




Example of a 91PE pulse




Example of a 110PE pulse




Example of a 111PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 29PE pulse




Example of a 23PE pulse




Example of a 128PE pulse




Example of a 110PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 143PE pulse




Example of a 127PE pulse




Example of a 129PE pulse




Example of a 124PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 111PE pulse




Example of a 130PE pulse




Example of a 128PE pulse




Example of a 97PE pulse




# 1176 PE distribution x=1000mm y=75mm




Example of a 156PE pulse



Example of a 122PE pulse



Example of a 126PE pulse



Example of a 152PE pulse

