




1040 PE distribution x=1000mm y=25mm




Example of a 56PE pulse




Example of a 77PE pulse




Example of a 84PE pulse




Example of a 68PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 60PE pulse




Example of a 53PE pulse




Example of a 65PE pulse




Example of a 75PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 80PE pulse




Example of a 72PE pulse




Example of a 73PE pulse




Example of a 64PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 43PE pulse




Example of a 36PE pulse




Example of a 101PE pulse




Example of a 113PE pulse




1040 PE distribution x=1000mm y=25mm




1040 PE distribution x=1000mm y=25mm




1040 PE distribution x=1000mm y=25mm




Example of a 84PE pulse




Example of a 56PE pulse




Example of a 78PE pulse




Example of a 84PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 64PE pulse




Example of a 41PE pulse




Example of a 83PE pulse




Example of a 90PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 90PE pulse




Example of a 98PE pulse




Example of a 104PE pulse




Example of a 83PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 93PE pulse




Example of a 130PE pulse




Example of a 275PE pulse




Example of a 237PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 52PE pulse




Example of a 274PE pulse




Example of a 71PE pulse




Example of a 48PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 55PE pulse




Example of a 50PE pulse




Example of a 50PE pulse




Example of a 58PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 315PE pulse




Example of a 282PE pulse




Example of a 53PE pulse




Example of a 57PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 50PE pulse




Example of a 32PE pulse




Example of a 71PE pulse




Example of a 117PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 54PE pulse




Example of a 55PE pulse




Example of a 69PE pulse




Example of a 57PE pulse




1040 PE distribution x=1000mm y=25mm




Example of a 52PE pulse



Example of a 48PE pulse



Example of a 63PE pulse



Example of a 67PE pulse

