




# 1020 PE distribution x=10mm y=25mm




Example of a 82PE pulse




Example of a 78PE pulse




Example of a 87PE pulse




Example of a 71PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 181PE pulse




Example of a 140PE pulse




Example of a 145PE pulse




Example of a 154PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 62PE pulse




Example of a 59PE pulse




Example of a 74PE pulse




Example of a 84PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 102PE pulse




Example of a 76PE pulse




Example of a 41PE pulse




Example of a 42PE pulse




# 1020 PE distribution x=10mm y=25mm




# 1020 PE distribution x=10mm y=25mm




# 1020 PE distribution x=10mm y=25mm




Example of a 121PE pulse




Example of a 137PE pulse




Example of a 110PE pulse




Example of a 82PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 110PE pulse




Example of a 310PE pulse



Example of a 274PE pulse




Example of a 158PE pulse







# 1020 PE distribution x=10mm y=25mm




Example of a 36PE pulse




Example of a 43PE pulse




Example of a 52PE pulse




Example of a 37PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 84PE pulse




Example of a 61PE pulse




Example of a 77PE pulse




Example of a 84PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 29PE pulse




Example of a 34PE pulse




Example of a 25PE pulse




Example of a 44PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 69PE pulse




Example of a 32PE pulse




Example of a 47PE pulse




Example of a 27PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 43PE pulse




Example of a 26PE pulse




Example of a 67PE pulse




Example of a 66PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 61PE pulse




Example of a 86PE pulse




Example of a 99PE pulse




Example of a 82PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 29PE pulse




Example of a 36PE pulse




Example of a 26PE pulse




Example of a 21PE pulse




# 1020 PE distribution x=10mm y=25mm




Example of a 97PE pulse



Example of a 55PE pulse



Example of a 48PE pulse



Example of a 265PE pulse

