




# 1050 PE distribution x=5mm y=75mm




Example of a 145PE pulse




Example of a 147PE pulse




Example of a 170PE pulse




Example of a 126PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 50PE pulse




Example of a 83PE pulse




Example of a 41PE pulse




Example of a 25PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 130PE pulse




Example of a 162PE pulse




Example of a 79PE pulse




Example of a 53PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 37PE pulse




Example of a 45PE pulse




Example of a 41PE pulse




Example of a 37PE pulse




# 1050 PE distribution x=5mm y=75mm




# 1050 PE distribution x=5mm y=75mm




# 1050 PE distribution x=5mm y=75mm




Example of a 194PE pulse




Example of a 163PE pulse




Example of a 38PE pulse




Example of a 49PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 76PE pulse




Example of a 86PE pulse



Example of a 48PE pulse




Example of a 30PE pulse







# 1050 PE distribution x=5mm y=75mm




Example of a 144PE pulse




Example of a 151PE pulse




Example of a 130PE pulse




Example of a 93PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 51PE pulse




Example of a 55PE pulse




Example of a 82PE pulse




Example of a 48PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 81PE pulse




Example of a 68PE pulse




Example of a 57PE pulse




Example of a 277PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 20PE pulse




Example of a 32PE pulse




Example of a 28PE pulse




Example of a 29PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 213PE pulse




Example of a 192PE pulse




Example of a 252PE pulse




Example of a 251PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 21PE pulse




Example of a 20PE pulse




Example of a 26PE pulse




Example of a 22PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 94PE pulse




Example of a 95PE pulse




Example of a 38PE pulse




Example of a 60PE pulse




# 1050 PE distribution x=5mm y=75mm




Example of a 53PE pulse



Example of a 40PE pulse



Example of a 42PE pulse



Example of a 22PE pulse

