




# 1284 PE distribution x=200mm y=75mm




Example of a 104PE pulse




Example of a 139PE pulse




Example of a 200PE pulse




Example of a 217PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 162PE pulse




Example of a 144PE pulse




Example of a 165PE pulse




Example of a 147PE pulse




1284 PE distribution x=200mm y=75mm




1284 PE distribution x=200mm y=75mm




1284 PE distribution x=200mm y=75mm




1284 PE distribution x=200mm y=75mm




# 1284 PE distribution x=200mm y=75mm




Example of a 93PE pulse




Example of a 75PE pulse




Example of a 157PE pulse




Example of a 126PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 107PE pulse




Example of a 80PE pulse



Example of a 114PE pulse




Example of a 114PE pulse







# 1284 PE distribution x=200mm y=75mm




Example of a 65PE pulse




Example of a 87PE pulse




Example of a 110PE pulse




Example of a 119PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 103PE pulse




Example of a 89PE pulse




Example of a 89PE pulse




Example of a 83PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 84PE pulse




Example of a 90PE pulse




Example of a 145PE pulse




Example of a 154PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 39PE pulse




Example of a 38PE pulse




Example of a 34PE pulse




Example of a 48PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 127PE pulse




Example of a 143PE pulse




Example of a 204PE pulse




Example of a 227PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 87PE pulse




Example of a 75PE pulse




Example of a 117PE pulse




Example of a 94PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 32PE pulse




Example of a 41PE pulse




Example of a 99PE pulse




Example of a 91PE pulse




# 1284 PE distribution x=200mm y=75mm




Example of a 49PE pulse



Example of a 49PE pulse



Example of a 62PE pulse



Example of a 90PE pulse

