




836 PE distribution x=500mm y=75mm




Example of a 46PE pulse




Example of a 34PE pulse




Example of a 32PE pulse




Example of a 30PE pulse




836 PE distribution x=500mm y=75mm




Example of a 75PE pulse




Example of a 79PE pulse




Example of a 41PE pulse




Example of a 53PE pulse




836 PE distribution x=500mm y=75mm




Example of a 52PE pulse




Example of a 58PE pulse




Example of a 61PE pulse




Example of a 62PE pulse




836 PE distribution x=500mm y=75mm




Example of a 66PE pulse




Example of a 57PE pulse




Example of a 48PE pulse




Example of a 46PE pulse




836 PE distribution x=500mm y=75mm




Example of a 53PE pulse




Example of a 56PE pulse




Example of a 47PE pulse




Example of a 75PE pulse




836 PE distribution x=500mm y=75mm




Example of a 111PE pulse




Example of a 120PE pulse




Example of a 75PE pulse




Example of a 75PE pulse




836 PE distribution x=500mm y=75mm




Example of a 100PE pulse




Example of a 105PE pulse




Example of a 113PE pulse




Example of a 91PE pulse




836 PE distribution x=500mm y=75mm




Example of a 77PE pulse



Example of a 86PE pulse



Example of a 83PE pulse



Example of a 80PE pulse

