




1025 PE distribution x=300mm y=25mm




Example of a 162PE pulse




Example of a 118PE pulse




Example of a 126PE pulse




Example of a 116PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 105PE pulse




Example of a 133PE pulse




Example of a 147PE pulse




Example of a 166PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 120PE pulse




Example of a 114PE pulse




Example of a 227PE pulse




Example of a 199PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 69PE pulse




Example of a 79PE pulse




Example of a 106PE pulse




Example of a 124PE pulse




1025 PE distribution x=300mm y=25mm




1025 PE distribution x=300mm y=25mm




1025 PE distribution x=300mm y=25mm




Example of a 129PE pulse




Example of a 145PE pulse




Example of a 153PE pulse




Example of a 141PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 200PE pulse




Example of a 160PE pulse




Example of a 384PE pulse




Example of a 300PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 94PE pulse




Example of a 92PE pulse




Example of a 69PE pulse




Example of a 59PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 65PE pulse




Example of a 63PE pulse




Example of a 105PE pulse




Example of a 123PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 71PE pulse




Example of a 84PE pulse




Example of a 155PE pulse




Example of a 126PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 214PE pulse




Example of a 212PE pulse




Example of a 40PE pulse




Example of a 75PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 80PE pulse




Example of a 87PE pulse




Example of a 291PE pulse




Example of a 284PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 64PE pulse




Example of a 155PE pulse




Example of a 169PE pulse




Example of a 272PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 41PE pulse




Example of a 57PE pulse




Example of a 49PE pulse




Example of a 54PE pulse




1025 PE distribution x=300mm y=25mm




Example of a 87PE pulse



Example of a 227PE pulse



Example of a 130PE pulse



Example of a 140PE pulse

