




1258 PE distribution x=2000mm y=25mm




Example of a 131PE pulse




Example of a 144PE pulse




Example of a 77PE pulse




Example of a 77PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 28PE pulse




Example of a 34PE pulse




Example of a 112PE pulse




Example of a 141PE pulse




1258 PE distribution x=2000mm y=25mm




1258 PE distribution x=2000mm y=25mm




1258 PE distribution x=2000mm y=25mm




Example of a 20PE pulse




Example of a 23PE pulse




Example of a 20PE pulse




Example of a 30PE pulse




1258 PE distribution x=2000mm y=25mm




1258 PE distribution x=2000mm y=25mm




Example of a 45PE pulse




Example of a 62PE pulse




Example of a 267PE pulse




Example of a 286PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 91PE pulse




Example of a 81PE pulse




Example of a 48PE pulse




Example of a 79PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 193PE pulse




Example of a 199PE pulse




Example of a 102PE pulse




Example of a 94PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 36PE pulse




Example of a 36PE pulse




Example of a 217PE pulse




Example of a 248PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 300PE pulse




Example of a 277PE pulse




Example of a 234PE pulse




Example of a 217PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 188PE pulse




Example of a 199PE pulse




Example of a 80PE pulse




Example of a 66PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 122PE pulse




Example of a 331PE pulse




Example of a 172PE pulse




Example of a 209PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 135PE pulse




Example of a 59PE pulse




Example of a 67PE pulse




Example of a 67PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 61PE pulse




Example of a 64PE pulse




Example of a 327PE pulse




Example of a 305PE pulse




1258 PE distribution x=2000mm y=25mm




Example of a 127PE pulse



Example of a 113PE pulse



Example of a 95PE pulse



Example of a 125PE pulse

