




# 1008 PE distribution x=1250mm y=75mm




Example of a 74PE pulse




Example of a 75PE pulse




Example of a 41PE pulse




Example of a 55PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 76PE pulse




Example of a 62PE pulse




Example of a 79PE pulse




Example of a 90PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 68PE pulse




Example of a 58PE pulse




Example of a 51PE pulse




Example of a 34PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 75PE pulse




Example of a 50PE pulse




Example of a 61PE pulse




Example of a 58PE pulse




# 1008 PE distribution x=1250mm y=75mm




# 1008 PE distribution x=1250mm y=75mm




# 1008 PE distribution x=1250mm y=75mm




Example of a 76PE pulse




Example of a 76PE pulse




Example of a 60PE pulse




Example of a 41PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 81PE pulse




Example of a 87PE pulse



Example of a 85PE pulse




Example of a 74PE pulse







# 1008 PE distribution x=1250mm y=75mm




Example of a 88PE pulse




Example of a 74PE pulse




Example of a 39PE pulse




Example of a 54PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 57PE pulse




Example of a 88PE pulse




Example of a 70PE pulse




Example of a 73PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 79PE pulse




Example of a 57PE pulse




Example of a 38PE pulse




Example of a 36PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 64PE pulse




Example of a 59PE pulse




Example of a 63PE pulse




Example of a 71PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 135PE pulse




Example of a 155PE pulse




Example of a 36PE pulse




Example of a 25PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 80PE pulse




Example of a 64PE pulse




Example of a 78PE pulse




Example of a 67PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 105PE pulse




Example of a 85PE pulse




Example of a 59PE pulse




Example of a 70PE pulse




# 1008 PE distribution x=1250mm y=75mm




Example of a 74PE pulse



Example of a 57PE pulse



Example of a 69PE pulse



Example of a 56PE pulse

