




# 1270 PE distribution x=75mm y=25mm




Example of a 106PE pulse




Example of a 89PE pulse




Example of a 132PE pulse




Example of a 102PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 266PE pulse




Example of a 144PE pulse




Example of a 200PE pulse




Example of a 351PE pulse




1270 PE distribution x=75mm y=25mm




# 1270 PE distribution x=75mm y=25mm




# 1270 PE distribution x=75mm y=25mm




1270 PE distribution x=75mm y=25mm




# 1270 PE distribution x=75mm y=25mm




Example of a 95PE pulse




Example of a 92PE pulse




Example of a 71PE pulse




Example of a 85PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 138PE pulse




Example of a 162PE pulse



Example of a 69PE pulse




Example of a 97PE pulse







# 1270 PE distribution x=75mm y=25mm




Example of a 67PE pulse




Example of a 47PE pulse




Example of a 67PE pulse




Example of a 61PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 107PE pulse




Example of a 146PE pulse




Example of a 254PE pulse




Example of a 252PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 58PE pulse




Example of a 37PE pulse




Example of a 39PE pulse




Example of a 28PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 95PE pulse




Example of a 110PE pulse




Example of a 105PE pulse




Example of a 148PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 64PE pulse




Example of a 82PE pulse




Example of a 46PE pulse




Example of a 58PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 301PE pulse




Example of a 285PE pulse




Example of a 182PE pulse




Example of a 162PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 50PE pulse




Example of a 57PE pulse




Example of a 45PE pulse




Example of a 45PE pulse




# 1270 PE distribution x=75mm y=25mm




Example of a 127PE pulse



Example of a 136PE pulse



Example of a 32PE pulse



Example of a 59PE pulse

