




# 1170 PE distribution x=1000mm y=25mm




Example of a 117PE pulse




Example of a 101PE pulse




Example of a 104PE pulse




Example of a 112PE pulse




# 1170 PE distribution x=1000mm y=25mm




## Example of a 126PE pulse




## Example of a 152PE pulse




## Example of a 146PE pulse




## Example of a 125PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 142PE pulse




Example of a 117PE pulse




Example of a 124PE pulse




Example of a 118PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 201PE pulse




Example of a 178PE pulse




Example of a 55PE pulse




Example of a 73PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 20PE pulse




Example of a 20PE pulse




Example of a 22PE pulse




Example of a 25PE pulse




1170 PE distribution x=1000mm y=25mm




# 1170 PE distribution x=1000mm y=25mm




Example of a 132PE pulse




Example of a 116PE pulse




Example of a 87PE pulse




Example of a 129PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 118PE pulse




Example of a 153PE pulse



Example of a 146PE pulse




Example of a 154PE pulse







# 1170 PE distribution x=1000mm y=25mm




Example of a 189PE pulse




Example of a 177PE pulse




Example of a 173PE pulse




Example of a 178PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 150PE pulse




Example of a 180PE pulse




Example of a 170PE pulse




Example of a 197PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 93PE pulse




Example of a 114PE pulse




Example of a 114PE pulse




Example of a 73PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 119PE pulse




Example of a 162PE pulse




Example of a 107PE pulse




Example of a 109PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 121PE pulse




Example of a 108PE pulse




Example of a 111PE pulse




Example of a 112PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 155PE pulse




Example of a 163PE pulse




Example of a 112PE pulse




Example of a 81PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 98PE pulse




Example of a 163PE pulse




Example of a 102PE pulse




Example of a 98PE pulse




# 1170 PE distribution x=1000mm y=25mm




Example of a 144PE pulse



Example of a 112PE pulse



Example of a 124PE pulse



Example of a 140PE pulse

