




1146 PE distribution x=1000mm y=75mm




Example of a 37PE pulse




Example of a 33PE pulse




Example of a 35PE pulse




Example of a 29PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 43PE pulse




Example of a 33PE pulse




Example of a 32PE pulse




Example of a 36PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 50PE pulse




Example of a 48PE pulse




Example of a 149PE pulse




Example of a 135PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 49PE pulse




Example of a 47PE pulse




Example of a 55PE pulse




Example of a 38PE pulse




1146 PE distribution x=1000mm y=75mm




1146 PE distribution x=1000mm y=75mm




1146 PE distribution x=1000mm y=75mm




Example of a 428PE pulse




Example of a 373PE pulse




Example of a 66PE pulse




Example of a 64PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 41PE pulse




Example of a 42PE pulse




Example of a 29PE pulse




Example of a 22PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 47PE pulse




Example of a 44PE pulse




Example of a 61PE pulse




Example of a 46PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 60PE pulse




Example of a 45PE pulse




Example of a 54PE pulse




Example of a 37PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 30PE pulse




Example of a 38PE pulse




Example of a 38PE pulse




Example of a 30PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 33PE pulse




Example of a 21PE pulse




Example of a 31PE pulse




Example of a 23PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 47PE pulse




Example of a 43PE pulse




Example of a 120PE pulse




Example of a 129PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 51PE pulse




Example of a 35PE pulse




Example of a 30PE pulse




Example of a 41PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 395PE pulse




Example of a 431PE pulse




Example of a 78PE pulse




Example of a 59PE pulse




1146 PE distribution x=1000mm y=75mm




Example of a 66PE pulse



Example of a 33PE pulse



Example of a 32PE pulse



Example of a 23PE pulse

