




# 1168 PE distribution x=0mm y=0mm




Example of a 91PE pulse




Example of a 85PE pulse




Example of a 118PE pulse




Example of a 111PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 62PE pulse




Example of a 35PE pulse




Example of a 53PE pulse




Example of a 74PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 111PE pulse




Example of a 97PE pulse




Example of a 118PE pulse




Example of a 122PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 154PE pulse




Example of a 137PE pulse




Example of a 113PE pulse




Example of a 125PE pulse




# 1168 PE distribution x=0mm y=0mm




# 1168 PE distribution x=0mm y=0mm




# 1168 PE distribution x=0mm y=0mm




Example of a 115PE pulse




Example of a 75PE pulse




Example of a 110PE pulse




Example of a 98PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 47PE pulse




Example of a 58PE pulse



Example of a 110PE pulse




Example of a 103PE pulse







# 1168 PE distribution x=0mm y=0mm




Example of a 154PE pulse




Example of a 134PE pulse




Example of a 149PE pulse




Example of a 152PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 128PE pulse




Example of a 160PE pulse




Example of a 166PE pulse




Example of a 163PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 76PE pulse




Example of a 61PE pulse




Example of a 105PE pulse




Example of a 86PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 31PE pulse




Example of a 47PE pulse




Example of a 35PE pulse




Example of a 83PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 108PE pulse




Example of a 74PE pulse




Example of a 94PE pulse




Example of a 98PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 110PE pulse




Example of a 105PE pulse




Example of a 82PE pulse




Example of a 77PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 106PE pulse




Example of a 68PE pulse




Example of a 123PE pulse




Example of a 92PE pulse




# 1168 PE distribution x=0mm y=0mm




Example of a 64PE pulse



Example of a 62PE pulse



Example of a 110PE pulse



Example of a 126PE pulse

