




# 1061 PE distribution x=1000mm y=75mm




Example of a 77PE pulse




Example of a 62PE pulse




Example of a 69PE pulse




Example of a 60PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 96PE pulse




Example of a 87PE pulse




Example of a 72PE pulse




Example of a 67PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 113PE pulse




Example of a 112PE pulse




Example of a 81PE pulse




Example of a 78PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 62PE pulse




Example of a 61PE pulse




Example of a 120PE pulse




Example of a 98PE pulse




# 1061 PE distribution x=1000mm y=75mm




# 1061 PE distribution x=1000mm y=75mm




# 1061 PE distribution x=1000mm y=75mm




Example of a 74PE pulse




Example of a 76PE pulse




Example of a 63PE pulse




Example of a 77PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 80PE pulse




Example of a 52PE pulse



Example of a 92PE pulse




Example of a 101PE pulse







# 1061 PE distribution x=1000mm y=75mm




Example of a 84PE pulse




Example of a 96PE pulse




Example of a 110PE pulse




Example of a 78PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 184PE pulse




Example of a 174PE pulse




Example of a 124PE pulse




Example of a 94PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 46PE pulse




Example of a 57PE pulse




Example of a 64PE pulse




Example of a 62PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 61PE pulse




Example of a 57PE pulse




Example of a 72PE pulse




Example of a 60PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 90PE pulse




Example of a 105PE pulse




Example of a 61PE pulse




Example of a 70PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 53PE pulse




Example of a 68PE pulse




Example of a 80PE pulse




Example of a 85PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 66PE pulse




Example of a 41PE pulse




Example of a 64PE pulse




Example of a 66PE pulse




# 1061 PE distribution x=1000mm y=75mm




Example of a 49PE pulse



Example of a 53PE pulse



Example of a 93PE pulse



Example of a 68PE pulse

